


Intertek



TESTING EVERYWHERE FOR...

...MARKETS ANYWHERE.

Web Site:www.intertek.com
Web Site:www.intertek.com.cn
China Toll-Free: 800 999 1338

ASIA PACIFIC

BANGLADESH (Dhaka)
Tel : (88-02) 815 6226
Fax : (88-02) 912 5866
E-mail:labtest.bangladesh@intertek.com

CHINA (Taiwan-Taipei)
Tel : (886-2) 6602 2888
Fax : (886-2) 6602 2889
E-mail:labtest.taiwan@intertek.com

CHINA (Guangzhou-Huangpu)
Tel : (86-20) 8396 6868
Fax : (86-20) 8222 7490/8135
E-mail:consumergoods.guangzhou@intertek.com

CHINA (Hong Kong)
Tel : (852) 2173 8888
Fax : (852) 2786 1903
E-mail:consumergoods.hongkong@intertek.com

CHINA (NingBo)
Tel : (86-574) 8720 2529
Fax : (86-574) 8720 2629
E-mail:leo.xiong@intertek.com

CHINA (Shanghai-Puxi)
Tel : (86-21) 6485 0139
Fax : (86-21) 6485 0592
E-mail:textile.shanghai@intertek.com

CHINA (Shanghai-Puxi)
Tel : (86-21) 6495 2121
Fax : (86-21) 6495 0740
E-mail:consumergoods.shanghai@intertek.com

CHINA (Shenzhen-Shenkou)
Tel : (86-755) 2686 1668
Fax : (86-755) 2667 6688
E-mail:consumergoods.shenzhen@intertek.com

CHINA (Tianjin)
Tel : (86-22) 8371 2202
Fax : (86-22) 8371 2205
E-mail:labtest.tianjin@intertek.com

INDIA (Haryana)
Tel : (91-124) 430 3590/91
Fax : (91-11) 2631 9512
E-mail:labtest.india@intertek.com

INDIA (Mumbai)
Tel : (91-22) 6797 6900
Fax : (91-22) 6703 1088
E-mail:labtest.india@intertek.com

INDIA (Tirupur)
Tel : (91-421) 223 2803/6
Fax : (91-421) 223 2800
E-mail:labtest.india@intertek.com

INDONESIA (Jakarta)
Tel : (62-21) 391 8584
Fax : (62-21) 391 8345
E-mail:labtest.indonesia@intertek.com

JAPAN (Osaka)
Tel : (81-6) 6303 1653
Fax : (81-6) 6303 1654
E-mail:labtest.japan@intertek.com

MALAYSIA (Kuala Lumpur)
Tel : (60-3) 7956 7989
Fax : (60-3) 7955 1989
E-mail:labtest@myairing.net

MALAYSIA (Penang)
Tel : (60-4) 645 7062
Fax : (60-4) 646 2302
E-mail:labtpg@tm.net.my

PHILIPPINES (Manila)
Tel : (63-2) 819 5841/8
Fax : (63-2) 817 2994
E-mail:labtest.phils@intertek.com

SINGAPORE
Tel : (65) 6388 8566
Fax : (65) 6382 6268
E-mail:labtest.singapore@intertek.com

SOUTH KOREA
Tel : (82-2) 2109 1255
Fax : (82-2) 2109 1259
E-mail:labtest.korea@intertek.com

- FITI (Associate)
Tel : (82-2) 3299 8021
Fax : (82-2) 3299 8153
E-mail:fiti@fiti.re.kr

THAILAND (Bangkok)
Tel : (66-2) 930 6554
Fax : (66-2) 939 0669
E-mail:labtest.thailand@intertek.com

VIETNAM (Ha Noi)
Tel : (84-4) 733 7094
Fax : (84-4) 733 7093
E-mail:labtest.vietnam@intertek.com

VIETNAM (Ho Chi Minh City)
Tel : (84-8) 297 1099
Fax : (84-8) 297 1098
E-mail:labtest.vietnam@intertek.com

EUROPE

CZECH REPUBLIC (Prague)
Tel : (420-251) 812 810
Fax : (420-251) 812 810
E-mail:labtest.larb@intertek.com

FRANCE (near Paris)
Tel : (33-2) 3209 3636
Fax : (33-2) 3209 3637
E-mail:consumergoods.larce@intertek.com

GERMANY (near Frankfurt)
Tel : (49-611) 716 5700
Fax : (49-611) 716 5789
E-mail:labtest.germany@intertek.com

ITALY (Florence)
Tel : (39-055) 790 873
Fax : (39-055) 791 198
E-mail:labtest.italy@intertek.com

PORTUGAL (Porto)
Tel : (351-22) 999 8080
Fax : (351-22) 999 8081
E-mail:labtest.portugal@intertek.com

POLAND (Warsaw)
Tel : (48-22) 873 9045
Fax : (48-22) 873 9045
E-mail:labtest.poland@intertek.com

TURKEY (Istanbul)
Tel : (90-212) 471 0065
Fax : (90-212) 471 1172
E-mail:labtest.turkey@intertek.com

U.K. (Leicester)
Tel : (44-116) 263 0330
Fax : (44-116) 263 0311/2
E-mail:labtest.uk@intertek.com

AMERICAS

BRAZIL (Sao Paulo)
Tel : (55-11) 3707 0650
Fax : (55-11) 3707 0656
E-mail:erica.missato@intertek.com

CANADA (Toronto)
Tel : (1-905) 678 7820
Fax : (1-905) 678 7131
E-mail:labtest-sc@intertek.com

COLOMBIA (Bogota)
Tel : (57-1) 256 8392
Fax : (57-1) 493 3255
E-mail:consumergoods.colombia@intertek.com

MEXICO (Mexico City)
Tel : (52-55) 5063 7190
Fax : (52-55) 5211 5030
E-mail:labtest.mexico@intertek.com

U.S.A. (Los Angeles)
Tel : (1-949) 349 1684
Fax : (1-949) 349 1690
E-mail:labtest.usa@intertek.com

U.S.A. (Miami)
Tel : (1-305) 513 3000
Fax : (1-305) 513 2856
E-mail:labtest.usa@intertek.com

U.S.A. (Oak Brook)
Tel : (630) 623 6060
Fax : (630) 623 6074
E-mail:labtest.usa@intertek.com

U.S.A. (Springfield)
Tel : (1-973) 924 2500
Fax : (1-973) 379 5232
E-mail:labtest.usa@intertek.com

AFRICA

EGYPT (Cairo)
Tel : (20-2) 4479 6612
Fax : (20-2) 4479 6611
E-mail:mohamed.brahim@intertek.com

MOROCCO (Casablanca)
Tel : (212-22) 298 181
Fax : (212-22) 298 190
E-mail:labtest.morocco@intertek.com

SOUTH AFRICA (Cape Town)
Tel : (27-21) 415 7000
Fax : (27-21) 418 5127
E-mail:labtest.southafrica@intertek.com

Other Offices

- Australia
- Belgium
- Bolivia
- Bulgaria
- Burma
- Chile
- Denmark
- Ecuador
- Greece
- Guatemala
- Haiti
- Hungary
- Ireland
- Israel
- Laos
- Mauritius
- Pakistan
- Paraguay
- Peru
- Romania
- Slovak Rep.
- Sri Lanka
- Switzerland
- Tunisia
- UAE
- Uruguay
- Venezuela

Intertek

Table I. Sample Size Code Letters

(Select the lot or batch size and your ideal inspection level to get the sample size code letter.)

Lot or Batch Size	Special Inspection Levels				General Inspection Levels		
	S-1	S-2	S-3	S-4	I	II	III
2 to 8	A	A	A	A	A	A	B
9 to 15	A	A	A	A	A	B	C
16 to 25	A	A	B	B	B	C	D
26 to 50	A	B	B	C	C	D	E
51 to 90	B	B	C	C	C	E	F
91 to 150	B	B	C	D	D	F	G
151 to 280	B	C	D	E	E	G	H
281 to 500	B	C	D	E	F	H	J
501 to 1200	C	C	E	F	G	J	K
1201 to 3200	C	D	E	G	H	K	L
3201 to 10000	C	D	F	G	J	L	M
10001 to 35000	C	D	F	H	K	M	N
35001 to 150000	D	E	G	J	L	N	P
150001 to 500000	D	E	G	J	M	P	Q
500001 and Over	D	E	H	K	N	Q	R

Table II. Single Sampling Plans For Normal Inspection

(Check the sample size by the code letter and select your preferred AQL.)

Sample size code letter	Sample size	Acceptance Quality Limit (Normal Inspection)																										
		0.010	0.015	0.025	0.040	0.065	0.10	0.15	0.25	0.40	0.65	1.0	1.5	2.5	4.0	6.5	10	15	25	40	65	100	150	250	400	650	1000	
A	2																											
B	3																											
C	5																											
D	8																											
E	13																											
F	20																											
G	32																											
H	50																											
J	80																											
K	125																											
L	200																											
M	315																											
N	500																											
P	800																											
Q	1250																											
R	2000																											

↓ = Use first sampling plan below arrow. If sample size equals, or exceeds lot or batch size, do 100 percent inspection.

↑ = Use first sampling plan above arrow.

Ac = Acceptance number

Reference : ANSI/ASQ Z1.4 / BS 6001 / DIN 40080 / ISO 2859 / NF X 06-022